

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

Spare Parts List of ClayPaky Sharpy Plus©

031118/001	Animation Disk rotation / insertion
371009/801	animation Disk
371010/801	Arm Front cover
371010/802	Arm Rear cover
371057/801	Base cover
371059/801	Beam mode lens assembly
371073/801	Cyan and Color Wheel
371073/802	Magenta Color Wheel
371073/803	Yellow Color Wheel
371081/801	Frost assembly
371110/801	Static gobo wheel with magnet
371131/801	Head top and botton cover assembly
371132/801	Lens cover
ALI025	Power Supply Unit
ALI026	Lamp Driver
CAB0IW/801	Yoke wirings Tilt; Pan; StrobeYun; 36V/0V; DataIn; 48V/36V/0V/0V; Led-P; HeadOut.
CAB0IX/801	Base wirings GE DMX N GE L LAMP/CNT 380V/0V.
CAB0IY/801	Lamp wirings YunInsM1; YunInsP1; Temp; Strobe; Hz-ZjOut.
CAB0IZ/801	Focus/Zoom/Prism/Frost wirings Focus(M7 P6 P); Zoom(M6 P4); PrismInsertion(M1 M3); Prism
CAB0J2/801	Color/Gobo/Animation Disk wirings Cyan; Magenta; Yellow; Animation Disk; Gobos.
CID02I	Pan belt
CID02J	Tilt belt
CID02K	Yun / Yellow belt
CID02L	Prism 8 facet belt
CID02M	Prism 4 facet belt
CID02N	Focus belt
CID02O	Zoom belt
CID02P	Static gobo belt
CID02Q	Rotating Gobo rotation belt
CID02R	Magenta belt
ETI0D1/001	Yoke sticker
FIC00J/001	MAGENTA filter
FIC00J/002	Color filter DARK RED
FIC00J/003	Color filter H.M.GREEN
FIC00J/004	Color filter DARK BLUE
FIC00J/005	Color filter CTB
FIC00J/006	Color filter DARK GREEN
FIC00K/001	CYAN filter
FIC00K/002	Color filter Blue Wood
FIC00K/003	Color filter CTO 2500 K
FIC00K/004	Color filter CTO 3200 K
FIC00K/005	Color filter LAVENDER
FIC00K/006	Color filter UV



Your online store for all stage lighting spare parts <https://lightspares.com>
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

FIC00L/001	YELLOW filter
FIC00L/002	Color filter LIGHT ORANGE
FIC00L/003	Color filter DARK ORANGE
FIC00L/004	Color filter AQUAMARINE
FIC00L/005	Color filter PINK
FIC00L/006	Color filter LIGHT GREEN
GOD01G/00	1st Gobo
GOD01G/00	2nd Gobo
GOD01G/00	3rd Gobo
GOD01G/00	4th Gobo
GOD01G/00	5th Gobo
GOD01G/00	6th Gobo
GOD01G/00	7th Gobo
GOD01G/00	8th Gobo
LAM000	Lamp
LEO02R	Front Lens
LEO03E	Zoom lens
LEO03F	Focus lens
MAG00A	Zoom, Focus, 8 facet Prims, Tilt, Rotating Gobo change magnet
MAG00B	Pan sensor magnet
MAG00D	4 facet Prism sensor magnet
MOP036	Motor Tilt / Pan
MOP036	Tilt; Pan
MOP037	Motor Focus / Zoom / Strobe
MOP037	Focus; Zoom
MOP038	Motor Yun (beam mode)
MOP038	Yun
MOP039	Motor 8 facet Prism insertion & rotation
MOP039	8 facet prism insertion/rotation
MOP03A	Motor Frost / 4 facet Prism insertion
MOP03A	Frost; 4 facet prism insertion
MOP03B	Motor Static Gobo
MOP03B	Static gobo
MOP03C	Motor Animation Disk insertion / Yellow
MOP03C	Animation Disk insertion; Yellow
MOP03D	Motor Animation Disk rotation
MOP03D	Animation Disk rotation
MOP03E	Motor Rotating gobo insertion
MOP03E	Rotating Gobo insertion
MOP03F	Motor Rotating Gobo rotation
MOP03F	Rotating Gobo rotation
MOP03H	Motor 4 facet prism / Magenta / Cyan
MOP03H	4 facet prism rotation; Magenta; Cyan
PLA07Y/001	Handle
PLA07Z/001	Base cover



Your online store for all stage lighting spare parts <https://lightspares.com>
©MS Lichttechnik GmbH, Hirschstettner Strasse 19A, 1220-Vienna, Austria

Order your Spare Parts online here -> lightspares.com Worldwide Express Delivery
Part or number not found? Send us a request! -> [Contact us!](#)

PRS00I/001	4 Facet Prism
PRS00I/002	8 Facet Prism
SCH09F	Driver Board (CTR 4) (Prism/Focus/Frost/Zoom)
SCH09G	Driver Board (CTR 2) (Cyan/Magenta/Yellow)
SCH09H	Driver Board (CTR 3) (StaticGobo / RotatingGobo / AnimationDisk)
SCH09I	5 pin DMX board
SCH09J	Gobo Rotation sensor
SCH09K	Pan and Tilt encoder board
SCH09L	Pan sensor
SCH09M	CPU Board
SCH09N	Sensor (Magenta, Yellow)
SCH09O	Sensor (Tilt, static gobo, Cyan)
SCH09P	Animation disk sensor
SCH09Q	Pan/Tilt board (CTR 1)
SCH09R	Sensor (prism rotation, prism change)
SCH0B4	Ethernet board
SCH0B5	Yun (Beam Mode) sensor
SCH0B6	Head PCB
SCH0B7	Rear Base PCB (Strobe/Yun)
SCH0B8	Sensor (Focus, Zoom)
VAC01R	DC Fan SUNON MB 40101V2 INLET to Pan/Tilt Card
VAC01S	DC Fan SUNON ME 50101V1 OUTLET to Lamp Driver
VAC01T	DC Fan SUNON MB 50151V1 INLET to Power Supply
VAC01U	DC Fan SUNON EE 92251B1 OUTLET to Lamp
VAC01V	DC Fan SUNON ME 50101V1 INLET to Lamp Driver
VAC01W	DC Fan SUNON ME 60151V3 INLET to Dimmer
VAC01X	DC Fan SUNON MF 50151V2 INLET to Gobo
VAC01Y	DC Fan SUNON ME 50151VX INLET to Lamp

