DJ ROLLER 150XT - DMX protocol - 8 bit

Channel	Value	Function	Type of control
1		**Declination of the drum**	
	0-255	Control of the declination of the drum rotation axis	proportional
2		**Rotation of the drum round its rotation axis**	
	0	No rotation	step
	1-125	Forwards rotation from fast to slow	proportional
	126-129	No rotation	step
	130-255	Backwards rotation from slow to fast	proportional
3		**Colours**	
	0 - 7	Open/white	step
	8 - 15	Turquoise	step
	16 - 23	Red	step
	24 - 31	Cyan	step
	32 - 39	Light green	step
	40 - 47	Magenta	step
	48 - 55	Light blue	step
	56 - 63	Yellow	step
	64 - 71	Green	step
	72 - 79	Pink	step
	80 - 87	Blue	step
	88 - 95	Orange	step
	96 - 103	UV	step
	104 - 111	Red/blue	step
	112 - 119	Yellow/Green	step
	120 - 127	Blue/purple	step
	128 - 189	Forwards rainbow effect from fast to slow	proportional
	190 - 193	No rotation	step
	194 - 255	Backwards rainbow effect from slow to fast	proportional
4		**Shutter,Strobe,Gobos**	
	0 - 5	Closed	step
	6 - 63	Open	step
	64-127	Strobe effect from slow to fast (max 8FPS)	proportional
	128-132	Closed	step
	133- 135	Reset of the fixture	step
	136-143	Open	step
	144-151	Closed	step
	152-159	Gobo 1	step
	160- 167	Gobo 2	step
	168- 175	Gobo 3	step
	176- 183	Gobo 4	step
	184- 191	Gobo 5	step
	192- 199	Gobo 6	step
	200- 207	Gobo 7	step
	208- 215	Gobo 8	step
	216- 223	Gobo 9	step
	224- 231	Gobo 10	step
	232-239	Gobo 11	step
	240-247	Gobo 12	step
	248-255	Gobo 13	step